## **INSTALLATION – CONTINUED**



## **ELECTRICAL CONNECTION**

## WARNING: Turn off the power supply.

- Open the shipping box [B] and place it in front of the desired location, as shown at the bottom of the page. Leave the baseboard [C] in its box to protect it during installation.
- Loosen the screw to remove the junction box cover [D]. There is one on each side of the baseboard.
- Carefully pull the two (2) wires [E] connected by a connection cap [F] until they come out of the junction box.
- 4. Depending on the type of installation, use one of the two connection diagrams on the next page. Connect the ground wire securely with the green screw [G] provided for this purpose.
- Connect the baseboard wires [E] to those of the power supply [H]. Tighten the wires securely in connection caps.
- 6. Push all wires into the junction box. Reposition the access cover then retighten the screw [D], making sure to place the power cable [H] in one of the two clearances [J].

Note: If the installation is made in an access cover knockout **[K]**, use a cable clamp to secure the power cable (cable clamp not included).

INSTALLATION AT A CONSTRUCTION SITE: The packaging is designed so that you can make the electrical connection while keeping the baseboard protected in its box. Punch the box [B] along the dotted lines [L] to access the junction box.

